

# Appendix

## Table of Contents

Additional Considerations for Racing .....	16-2
Carburetor .....	16-2
Spark Plug .....	16-2
<i>Spark Plug Inspection</i> .....	16-3
Troubleshooting Guide .....	16-4
General Lubrication .....	16-8
<i>Lubrication</i> .....	16-8
Nut, Bolt, and Fastener Tightness .....	16-8
<i>Tightness Inspection</i> .....	16-8
Standard Torque Table .....	16-9
Unit Conversion Table .....	16-10

## 16-2 APPENDIX

### Additional Considerations for Racing

This motorcycle has been manufactured for use in a reasonable and prudent manner and as a vehicle only. However, some may wish to subject this motorcycle to abnormal operation, such as would be experienced under racing conditions. KAWASAKI STRONGLY RECOMMENDS THAT ALL RIDERS RIDE SAFELY AND OBEY ALL LAWS AND REGULATIONS CONCERNING THEIR MOTORCYCLE AND ITS OPERATION.

Racing should be done under supervised conditions, and recognized sanctioning bodies should be contacted for further details. For those who desire to participate in competitive racing or related use, the following technical information may prove useful. However, please note the following important points.

- You are entirely responsible for the use of your motorcycle under abnormal conditions such as racing, and Kawasaki shall not be liable for any damages which might arise from such use.
- Kawasaki's Limited Motorcycle Warranty and Limited Emission Control Systems Warranty specifically exclude motorcycles which are used in competitive or related uses. Please read the warranty carefully.
- Motorcycle racing is a very sophisticated sport, subject to many variables. The following information is theoretical only, and Kawasaki shall not be liable for any damages which might arise from alterations utilizing this information.
- When the motorcycle is operated on public roads, it must be in its original state in order to ensure safety and compliance with applicable regulations.


### Carburetors:

Sometimes an alteration may be desirable for improved performance under special conditions when proper mixture is not obtained after the carburetors have been properly adjusted, and all parts cleaned and found to be functioning properly.

If the engine still exhibits symptoms of overly lean carburetion after all maintenance and adjustments are correctly performed, the main jet can be replaced with a smaller or larger one. A smaller numbered jet gives a leaner mixture and a larger numbered jet a richer mixture.

For the models other than the US model, a certain amount of adjustment can be made by changing the position of the needle. There are five grooves at the top of the needle. Changing the position of the clip to a groove closer to the bottom raises the needle, which makes the mixture richer at a given position of the throttle valve.

### Jet Needle




### Spark Plug:

The spark plug ignites the fuel/air mixture in the combustion chamber. To do this effectively and at the proper time, the correct spark plug must be used, and the spark plug must be kept clean and adjusted.

Test have shown the plug listed in the "General Specifications" section in the "General Information" chapter to be the best plug for general use.

Since spark plug requirements change with the ignition and carburetion adjustments and with riding conditions, whether or not a spark plug of a correct heat range is used should be determined by removing and inspecting the plug.

### Spark Plug




## Spark Plug Condition



Carbon Fouling



Oil Fouling



Normal Operation



Overheating

When a plug of the correct heat range is being used, the electrodes will stay hot enough to keep all the carbon burned off, but cool enough to keep from damaging the engine and the plug itself. This temperature is about 400 – 800°C (750 – 1,450°F) and can be judged by noting the condition and color of the ceramic insulator around the center electrode. If the ceramic is clean and of a light brown color, the plug is operating at the right temperature.

A spark plug for higher operating temperatures is used for racing. Such a plug is designed for better cooling efficiency so that it will not overheat and thus is often called a “colder” plug. If a spark plug with too high a heat range is used – that is, a “cold” plug that cools itself too well – the plug will stay too cool to burn off the carbon, and the carbon will collect on the electrodes and the ceramic insulator.

The carbon on the electrodes conducts electricity, and can short the center electrode to ground by either coating the ceramic insulator or bridging across the gap. Such a short will prevent an effective spark. Carbon build-up on the plug can also cause other troubles. It can heat up red-hot and cause preignition and knocking, which may eventually burn a hole in the top of the piston.

## Spark Plug Inspection


- Remove the spark plug and inspect the ceramic insulator.
- ★ Whether or not the right temperature plug is being used can be ascertained by noting the condition of the ceramic insulator around the electrode. A light brown color indicates the correct plug is being used. If the ceramic is black, it indicates that the plug is firing at too low a temperature, so the next hotter type (NGK B8ES) should be used instead. If the ceramic is white, the plug is operating at too high a temperature and it should be replaced with the next colder type.

CAUTION

- If the spark plug is replaced with a type other than the standard plug, make certain the replacement plug has the same thread pitch and reach (length of threaded portion) and the same insulator type (regular type or projected type) as the standard plug.

- If the plug reach is too short, carbon will build up on the plug hole threads in the cylinder head, causing overheating and making it very difficult to insert the correct spark plug later.
- If the reach is too long, carbon will build up on the exposed spark plug threads causing overheating, preignition, and possibly burning a hole in the piston top. In addition, it may be impossible to remove the plug without damaging the cylinder head.

## Plug Reach



## Standard Spark Plug Threads

Diameter	: 14 mm
Pitch	: 1.25 mm
Reach	: 19.0 mm

## NOTE

- The heat range of the spark plug functions like a thermostat for the engine. Using the wrong type of spark plug can make the engine run too hot (resulting in engine damage) or too cold (with poor performance, misfiring, and stalling). The standard plug has been selected to match the normal usage of this motorcycle in combined street and highway riding. Unusual riding conditions may require a different spark plug heat range. For racing, install the colder plug.

.....  
**Trouble shooting Guide**  
 .....

**NOTE**

○This is not an exhaustive list, giving every possible cause for each problem listed. It is meant simply as a rough guide to assist the troubleshooting for some of the more common difficulties. Electrical troubleshooting is not covered here due to its complexity. For electrical problems, refer to the appropriate heading in Electrical System.

**Engine Doesn't Start; Starting Difficulty**

**Engine won't turn over**

- Cylinder, piston seizure
- Connecting rod small end seizure
- Connecting rod big end seizure
- Transmission gear or crankcase bearing seizure
- Kickstarter return spring broken
- Kick ratchet gear not engaging

**No fuel flow**

- No fuel in tank
- Sticking of the valve in valve in the automatic fuel tap
- Fuel tap vacuum hose clogged
- Tank cap air vent obstructed
- Fuel tap clogged
- Fuel line clogged
- Float valve clogged

**Engine flooded**

- Float level too high
- Float valve worn or stuck open
- Starting technique faulty  
 (When flooded, kick with the throttle fully open to allow more air to reach the engine)

**No spark, spark weak**

- Ignition switch not on
- Engine stop switch turned off
- Spark plug dirty, damaged, or maladjusted
- Spark plug cap or high tension wiring damaged
- Spark plug cap shorted or not in good contact
- Ignition coil damaged
- Ignition coil register open
- CDI unit broken
- Pickup coil broken or maladjusted
- Flywheel magneto damaged
- Pulser rotor damaged
- Ignition or engine stop switch shorted
- Wiring shorted or open

**Fuel/air mixture incorrect**

- Throttle stop screw maladjusted
- Pilot jet or air passage clogged
- Air cleaner clogged, poorly sealed, or missing
- Air cleaner duct loose
- Starter jet clogged

**Compression low**

- Cylinder, piston worn
- Piston ring bad (worn, weak, broken, or sticking)
- Piston ring/land clearance excessive
- Cylinder head gasket or base gasket damaged

- Cylinder head not sufficiently tightened down
- Cylinder head warped
- Spark plug loose
- Crankshaft oil seal deteriorated or damaged
- Reed valve damaged
- Rotary valve cover oil seal deteriorated or damaged
- Rotary valve cover large O-ring deteriorated or damaged

**Poor Running at Low Speed**

**Spark weak**

- Spark plug dirty, damaged, or maladjusted
- Spark plug cap or high tension wiring damaged
- Spark plug cap shorted or not in good contact
- Ignition coil damaged
- CDI unit broken pickup coil broken or maladjusted
- Flywheel magneto damaged
- Pulser rotor damaged

**Fuel/air mixture incorrect**

- Throttle stop screw maladjusted
- Carburetors not synchronizing
- Pilot jet or air passage clogged
- Air cleaner clogged, poorly sealed, or missing
- Air cleaner duct loose
- Starter plunger stuck open
- Float level too high or too low
- Fuel tank air vent obstructed

**Compression low**

- Cylinder, piston worn
- Piston ring bad (worn, weak, broken or sticking)
- Piston ring/land clearance excessive
- Cylinder head gasket or base gasket damaged
- Cylinder head not sufficiently tightened down
- Cylinder head warped
- Spark plug loose
- Crankshaft oil seal deteriorated or damaged
- Reed valve damaged
- Rotary valve cover oil seal deteriorated or damaged
- Rotary valve cover large O-ring deteriorated or damaged

**Poor Running No Power at High Speed**

**Firing incorrect**

- Spark plug dirty, damaged, or maladjusted
- Spark plug cap or high tension wiring damaged
- Spark plug cap shorted or not in good contact
- Ignition coil damaged
- Ignition timing malfunction
- Ignition coil register open
- CDI unit broken
- Pickup coil broken or maladjusted

**Fuel/air mixture incorrect**

- Main jet clogged or wrong size
- Jet needle or needle jet worn
- Jet needle clip in wrong position
- Float level too high or too low

Air jet or air passage clogged  
 Air cleaner clogged, poorly sealed, or missing  
 Starter plunger stuck open  
 Fuel to carburetor insufficient  
 Water or foreign matter in fuel  
 Fuel tank air vent obstructed  
 Fuel line clogged  
 Fuel tap clogged  
 Air cleaner duct loose

**Compression low**

Cylinder, piston worn  
 Piston ring bad (worn, weak, broken, or sticking)  
 Piston ring/land clearance excessive  
 Cylinder head gasket or base gasket damaged  
 Cylinder head not sufficiently tightened down  
 Cylinder head warped  
 Spark plug loose  
 Crankshaft oil seal deteriorated or damaged  
 Reed valve damaged  
 Rotary valve cover oil seal deteriorated or damaged  
 Rotary valve cover large O-ring deteriorated or damaged

**Oil and fuel/air mixture incorrect**

Oil pump cable maladjusted  
 Throttle control cable maladjusted  
 Crankshaft oil seal deteriorated or damaged  
 Rotary valve cover oil seal deteriorated or damaged  
 Rotary valve cover large O-ring deteriorated or damaged

No oil in oil tank  
 Oil pump damaged  
 Oil line or check valve clogged  
 Air in oil pump or oil line

**Engine rpm will not rise properly**

Starter plunger stuck open  
 Float level too high or too low  
 Main jet clogged  
 Throttle valve does not fully open  
 Air cleaner clogged  
 Muffler clogged  
 Water or foreign matter in fuel  
 Cylinder exhaust port clogged  
 Brake dragging  
 Clutch slipping  
 Overheating  
 Transmission oil level too high  
 Transmission oil viscosity too high  
 Crankshaft bearing worn or damaged

**Knocking**

Ignition timing malfunction  
 Carbon built up in combustion chamber  
 Fuel poor quality or incorrect  
 Spark plug incorrect

**Overheating****Firing incorrect**

Spark plug dirty, damaged, or maladjusted  
 Ignition timing malfunction

**Fuel/air mixture incorrect**

Main jet clogged or wrong size

Float level too low  
 Air cleaner clogged  
 Air cleaner duct loose

**Oil and fuel/air mixture incorrect**

Throttle control cable maladjusted  
 No oil in oil tank  
 Oil pump damaged  
 Oil line or check valve clogged  
 Air in oil pump or oil line

**Compression high**

Carbon built up in combustion chamber

**Engine load faulty**

Clutch slipping  
 Transmission oil level too high  
 Brake dragging

**Gauge incorrect**

Water temperature gauge broken  
 Water temperature sensor broken

**Coolant incorrect**

Coolant level too low  
 Coolant deteriorated

**Cooling system component incorrect**

Radiator clogged  
 Thermostat trouble  
 Radiator cap trouble  
 Water pump not rotating  
 Water pump impeller damaged

**Over Cooling****Gauge incorrect**

Water temperature gauge broken  
 Water temperature sensor broken

**Cooling system component incorrect**

Thermostat trouble

**Fuel and Oil Consumption Excessive****Idle too fast**

Throttle stop screw maladjusted  
 Throttle control cable catching or poorly adjusted

**Fuel/air mixture too rich**

Jet needle or needle jet worn  
 Starter plunger stuck open  
 Float level too high  
 Air cleaner clogged

**Compression low**

Cylinder, piston worn  
 Piston ring bad (worn, weak, broken, or sticking)  
 Piston ring/land clearance excessive  
 Cylinder head gasket or base gasket damaged  
 Cylinder head not sufficiently tightened down  
 Cylinder head warped  
 Spark plug loose  
 Crankshaft oil seal deteriorated or damaged  
 Reed valve damaged  
 Rotary valve cover oil seal deteriorated or damaged  
 Rotary valve cover large O-ring deteriorated or damaged

**Exhaust obstructed**

Muffler clogged  
 Cylinder exhaust port clogged

## 16-6 APPENDIX

### Engine load faulty

- Clutch slipping
- Transmission oil level too high
- Brake dragging

### Clutch Operation Faulty

#### Clutch slipping

- No clutch lever play
- Friction plate worn or warped
- Steel plate worn or warped
- Clutch spring weak
- Clutch cable maladjusted
- Clutch inner cable catching
- Clutch release mechanism trouble
- Clutch hub or housing unevenly worn

#### Clutch not disengaging properly

- Clutch lever play excessive
- Clutch plate warped or too rough
- Clutch spring tension uneven
- Transmission oil deteriorated
- Transmission oil viscosity too high
- Clutch housing gear frozen on drive shaft
- Clutch release mechanism trouble

### Gear Shifting Faulty

#### Doesn't into gear; shift pedal doesn't return

- Clutch not disengaging
- Shift fork bent or seized
- Shift return spring weak or broken
- Shift lever broken
- Shift return spring pin loose
- Shift pawl spring broken
- Set levers binding
- External shift mechanism arm pawl worn

#### Jumps out of gear

- Shift fork worn
- Gear groove worn
- Gear dogs, holes, and/or recesses worn
- Shift drum groove worn
- Shift drum set lever spring weak or broken
- Shift fork guide pin or collar worn
- Drive shaft, output shaft, and/or gear splines worn

#### Overshifts

- Shift drum set lever spring weak or broken

### Abnormal Engine Noise

#### Knocking

- Ignition timing malfunction
- Carbon built up in combustion chamber
- Fuel poor quality or incorrect
- Overheating
- Spark plug incorrect

#### Piston slap

- Cylinder/piston clearance excessive
- Cylinder, piston worn
- Connecting rod bent
- Piston pin, piston pin hole worn

### Other noise

- Connecting rod small end clearance excessive
- Connecting rod big end clearance excessive
- Piston ring worn, broken, or stuck
- Piston seizure or damaged
- Cylinder head gasket leaking
- Exhaust pipe leaking at cylinder connection
- Crankshaft runout excessive
- Engine mount loose
- Crankshaft bearing worn

### Abnormal Drive Train Noise

#### Clutch noise

- Primary gear cam damper damaged
- Clutch rubber damper deteriorated
- Clutch housing/friction plate clearance excessive
- Clutch housing gear/primary gear backlash excessive
- Metal chip jammed in clutch housing gear teeth

#### Transmission noise

- Crankcase bearing worn
- Transmission gear worn or chipped
- Metal chip jammed in gear teeth
- Transmission oil insufficient or too thin
- Kick ratchet gear not properly disengaging from kick gear
- Kick idle gear worn or chipped

#### Drive chain noise

- Chain worn
- Rear and/or engine sprocket(s) worn
- Chain lubrication insufficient
- Rear wheel misaligned

### Abnormal Frame Noise

#### Front fork noise

- Oil insufficient or too thin
- Spring weak or broken

#### Rear shock absorber noise

- Shock absorber damaged

#### Disc brake noise

- Pad installed incorrectly
- Pad surface glazed
- Disc warped
- Caliper damaged
- Cylinder damaged

#### Other noise

- Bracket, nut, bolt, etc. not properly mounted or tightened

### Exhaust Smoke

#### Excessive white smoke

- Oil pump cable maladjusted
- Throttle control cable maladjusted
- Engine oil poor quality or incorrect
- Crankshaft oil seal damaged
- Rotary valve cover oil seal deteriorated or damaged

Rotary valve cover large O-ring deteriorated or damaged

**Brownish smoke**

Air cleaner clogged  
Main jet too large or fallen off  
Starter plunger stuck open  
Float level too high

**Handling and/or Stability Unsatisfactory**

**Handlebar hard to turn**

Control cable routing incorrect  
Wiring routing incorrect  
Steering stem locknut too tight  
Bearing roller damaged  
Bearing race dented or worn  
Steering stem lubrication inadequate  
Steering stem bent  
Tire air pressure too low

**Handlebar shakes or excessively vibrates**

Tire worn  
Swing arm bushing or needle bearing damaged  
Rim warped  
Front, rear axle runout excessive  
Wheel bearing worn  
Handlebar clamp loose

**Handlebar pulls to one side**

Frame bent  
Wheel misalignment  
Swing arm bent or twisted  
Swing arm pivot shaft runout excessive  
Steering stem bent  
Front fork leg bent  
Right/left front fork oil level uneven

**Shock absorption unsatisfactory**

(Too hard)  
Front fork oil excessive  
Front fork oil viscosity too high  
Front fork air pressure too high  
Tire air pressure too high  
Rear suspension maladjusted  
(Too soft)  
Front fork oil insufficient and/or leaking  
Front fork oil viscosity too low  
Front fork air pressure too low  
Front fork, rear shock absorber spring(s) weak  
Rear shock absorber oil leaking  
Rear shock absorber gas leaking

**Brake Doesn't Hold**

**Disc brake**

Air in the brake line  
Pad or disc worn  
Brake fluid leak  
Brake plunger of AVDS damaged  
Disc warped  
Contaminated pad  
Brake fluid deteriorated  
Primary cup or secondary cup damaged  
Master cylinder scratched inside

**Battery Discharged**

Battery faulty (e.g., plates sulphated, shorted through sedimentation, electrolyte level too low)  
Battery lead making poor contact  
Regulator/rectifier damaged  
Ignition switch damaged  
Load excessive (e.g., bulb of excessive wattage)  
Flywheel magneto damaged  
Stator coil open or short  
Wiring faulty

**Battery Overcharged**

Battery damaged  
Regulator/rectifier trouble

General Lubrication

Lubrication

- Before lubricating each part, clean off any rusty spots with rust remover and wipe off any grease, oil, dirt, or grime.
- Lubricate the points listed below with indicated lubricant.

NOTE

○ Whenever the vehicle has been operated under wet or rainy conditions, or especially after using a high-pressure spray water, perform the general lubrication.

Pivots: Lubricate with Motor Oil.

- Side Stand
- Clutch Lever
- Brake Lever
- Brake Pedal Shaft
- Rear Brake Rod Joint
- Kick Pedal

Points: Lubricate with Grease.


- Throttle Inner Cable Lower End
- Oil Pump Inner Cable Lower End
- Speedometer Inner Cable\*

\*Grease the lower part of the inner cable sparingly.

Cables: Lubricate with Motor Oil.

- Choke Cable
- Throttle Control Cable
- Oil Pump Cable

Cable Lubrication



Nut, Bolt, and Fastener Tightness

Tightness Inspection

- Check the tightness of the bolts and nuts listed here. Also, check to see that each cotter pin is in place and in good condition.

NOTE

○ For the engine fasteners, check the tightness of them when the engine is cold (at room temperature).

- If there are loose fasteners, retorque them to the specified torque following the specified tightening sequence. Refer to the appropriate chapter for torque specifications. If torque specifications are not in the appropriate chapter, see the Standard Torque Table. First loosen each fastener by 1/2 turn, then tighten it.
- ★ If cotter pins are damaged, replace them with new ones.

Nut, Bolt, and Fastener to be checked

Wheels:

- Front Axle Nut
- Front Axle Clamp Bolts
- Rear Axle Nut
- Chain Adjuster Clamp Bolts

Brakes:

- Front Master Cylinder Clamp Bolts
- Front Caliper Mounting Bolts
- Rear Master Cylinder Mounting Bolt
- Rear Caliper Holder Fixing Bolt
- Rear Caliper Holder Collar Bolt
- Brake Lever Pivot Nut
- Brake Pedal Bolt
- Brake Rod Joint Cotter Pin

Suspension:

- Front Fork Clamp Bolts
- Front Fender Mounting Bolts and Nuts
- Rear Shock Absorber Mounting Bolts
- Swing Arm Pivot Shaft Nut
- Uni-trak Link Nuts
- Swing Arm Holder Mounting Bolts

Steering

- Stem Head Nut
- Handlebar Holder Bolts
- Handlebar Holder Clamp Bolts

Engine:

- Engine Mounting Bolts
- Cylinder Head Bolts
- Muffler Mounting Nuts
- Muffler Mounting Bolts
- Clutch Lever Pivot Nut

Others:

- Side Stand Bolt
- Front Footpeg Mounting Bolts
- Rear Frame Mounting Bolts
- Footpeg Bracket Mounting Bolts



.....  
**Standard Torque Table**  
 .....

This table relating tightening torque to thread diameter, lists the basic torque for bolts and nuts. Use this table for only the bolts and nuts which do not require a specific torque value. Refer to each chapter for reference to these features. All of the values are for use with dry solvent-cleaned threads.

**General Fasteners**

Threads dia. (mm)	Torque		
	N-m	kg-m	ft-lb
5	3.4 - 4.9	0.35 - 0.50	30 - 43 in-lb
6	5.9 - 7.8	0.60 - 0.80	52 - 69 in-lb
8	14 - 19	1.4 - 1.9	10.0 - 13.5
10	25 - 34	2.6 - 3.5	19.0 - 25
12	44 - 61	4.5 - 6.2	33 - 45
14	73 - 98	7.4 - 10.0	54 - 72
16	115 - 155	11.5 - 16.0	83 - 115
18	165 - 225	17.0 - 23	125 - 165
20	225 - 325	23 - 33	165 - 240

**16-10 APPENDIX**

**Unit Conversion Table**

**Prefixes for Units:**

Prefix	Symbol	Power
mega	M	x 1,000,000
kilo	k	x 1,000
centi	c	x 0.01
milli	m	x 0.001
micro	μ	x 0.000001

**Units of Mass:**

kg	x	2.205	=	lb
g	x	0.03527	=	oz

**Units of Volume:**

L	x	0.2642	=	gal (US)
L	x	0.2200	=	gal (imp)
L	x	1.057	=	qt (US)
L	x	0.8799	=	qt (imp)
L	x	2.113	=	pint (US)
L	x	1.816	=	pint (imp)
mL	x	0.03381	=	oz (US)
mL	x	0.02816	=	oz (imp)
mL	x	0.06102	=	cu in

**Units of Force:**

N	x	0.1020	=	kg
N	x	0.2248	=	lb
kg	x	9.807	=	N
kg	x	2.205	=	lb

**Units of Length:**

km	x	0.6214	=	mile
m	x	3.281	=	ft
mm	x	0.03937	=	in

**Units of Torque:**

N-m	x	0.1020	=	kg-m
N-m	x	0.7376	=	ft-lb
N-m	x	8.851	=	in-lb
kg-m	x	9.807	=	N-m
kg-m	x	7.233	=	ft-lb
kg-m	x	86.80	=	in-lb

**Units of Pressure:**

kPa	x	0.01020	=	kg/cm <sup>2</sup>
kPa	x	0.1450	=	psi
kPa	x	0.7501	=	cm Hg
kg/cm <sup>2</sup>	x	98.07	=	kPa
kg/cm <sup>2</sup>	x	14.22	=	psi
cm Hg	x	1.333	=	kPa

**Units of Speed:**

km/h	x	0.6214	=	mph
------	---	--------	---	-----

**Units of Power:**

kW	x	1.360	=	PS
kW	x	1.341	=	HP
PS	x	0.7355	=	kW
PS	x	0.9863	=	HP

**Units of Temperature:**

$$\frac{9 (^{\circ}\text{C} + 40)}{5} - 40 = ^{\circ}\text{F}$$

$$\frac{5 (^{\circ}\text{F} + 40)}{9} - 40 = ^{\circ}\text{C}$$

